





<u>2</u>


































































































































































































































































































































4653970







7x 6102828









6141594



4619515











6022023





















6172421





Customer Service

Kundenservice

Service Consommateurs Servicio Al Consumidor

LEGO.com/service or dial



: 00800 5346 5555 : 1-800-422-5346















UNIKITTY! Series © & $^{\text{TM}}$ Warner Bros. Ent. Inc. & The LEGO Group. LEGO, the LEGO logo, the Brick and Knob configurations and UNIKITTY © & $^{\text{TM}}$ The LEGO Group. ©2018 The LEGO Group.

All new characters and elements © & ™ WBEI and The LEGO Group. WB SHIELD: TM & © WBEI. (s18)